

# UNIWELL POS AUSTRALIA SELF HELP

## Tare Tables



Details	Description
Revision No.	20210210
Hardware / Firmware	All HX Models – V4.00 to Current
Equipment	Uniwell POS Terminal
Author	GD

Requirements	Description
Pre Requisites	Products Created
Duration	3 mins
Related Documents	Creating / Modifying Products
Additional Information	None


## Outcome

**i** \*\*\* Program weights to be deducted when a scale item is selected \*\*\*

It is a requirement by law to deduct the weight of any bag or container used while weighing food items when placed on the scale. The tare table allows the POS to automatically deduct the weight of the container allowing for calculation of the weighed items only ignoring the weight of the bag/container.

### \*\*\* Start Of Self-Help Instructions \*\*\*


1. Exit sales screen and enter PROGRAM mode:




2. Select Others → TARE TABLE




- Rename 'Tare 01' to a suitable reference, ie 5 Grams. Highlight position 1 then click inside the 'NAME' field



- Tap inside the 'TARE WEIGHT' field and use the number pad to press '5' for 5 grams.



- Repeat the above steps for other weights, ie 10 grams, 15 grams etc.



- Press 'OK' to save and exit.
- Press 'PLU' Button to enter PLU programming screen.



8. Select desired product from the list followed by the 'TYPE' tab and then from the Tare Table '5 Grams'.

The screenshot shows the 'PLU' configuration window. The 'Type' tab is selected and highlighted with a red box and the number '2'. In the left-hand list, the 'Carrots' entry is highlighted with a red box and the number '1'. In the right-hand configuration area, the 'Tare Table' dropdown menu is set to '5 Grams' and is highlighted with a red box and the number '3'. The interface includes a search bar, a list of PLU items, and various configuration options like 'Scalable PLU' and 'Tare Table'.

9. This completes the Auto Tare programming.

**\*\*\* End Of Self Help Instructions \*\*\***